

QUARTZ QF500F


 LISTED
SUITABLE FOR WET LOCATIONS

WARNING: RISK OF FIRE AND ELECTRICAL SHOCK. INSTALL IN ACCORDANCE WITH NATIONAL AND LOCAL ELECTRIC CODES USING A QUALIFIED ELECTRICIAN

CAUTION:

- TURN OFF ELECTRICITY, remove fuse or switch off circuit breaker.
- THERE IS A RISK OF FIRE AND ELECTRICAL SHOCK. INSTALL IN ACCORDANCE WITH NATIONAL AND LOCAL ELECTRICAL CODES USING A QUALIFIED ELECTRICIAN.
- USE OUTDOORS ONLY. Mount fixture at least 18 inches from any combustible material.

WIRING DIAGRAM:



LAMP INSTALLATION OR RELAMPING:

1. Use Type "T" 500 watt double ended lamp. RAB catalog # LQ500. Use 500 watt lamp Maximum.
2. Disconnect power and let lamp cool if it was in operation.
3. Release top latch and swing down front cover.
4. **IMPORTANT: DO NOT TOUCH LAMP WITH BARE HANDS.** Touching lamp with bare hands will cause premature lamp failure. Use gloves or cloth to hold lamp. While positioning bump in lamp outward from fixture insert the lamp into one end of the spring loaded socket and then fit the other end of the lamp into the other socket and release.
5. Swing up front cover and latch, reconnect power.

FIXTURE INSTALLATION:

1. Make sure electricity is turned OFF.
2. Thread arm through mounting cover and secure with locknut.
3. Connect wires as shown in diagram.
4. Attach cover to junction box.
5. Put weatherproof gasket in position under cover.
6. Aim floodlight in direction desired and tighten locknut and arm bottom. Keep fixture within 2 degrees of horizontal or lamp will fail prematurely.
7. Install lamp (see instructions).
8. Turn on power.