AcuityControls.


Sensor Switch...


LSXR

Interchangeable Lens Occupancy Sensors Wiring Diagrams




Line Voltage Interchangeable Lens Fixture Mount, Switching and Dimming Line Voltage Interchangeable Lens Fixture Mount: 2-Pole






Line Voltage Interchangeable Lens Fixture Mount: 2P w/ Single Zone On/Off Photocontrol


Line Voltage Interchangeable Lens Fixture Mount: 2-Pole






Interchangeable Lens Occupancy Sensors Wiring Diagrams


Line Voltage Interchangeable Lens Fixture Mount: 2-Phase



Line Voltage Interchangeable Lens Fixture Mount (HVOLT)

Line Voltage Interchangeable Lens Fixture Mount: 2-Pole (HVOLT)





Line Voltage Interchangeable Lens Fixture Mount: 2P w/ Single Zone On/Off Photocontrol (HVOLT) Line Voltage Interchangeable Lens Fixture Mount: 2-Phase (HVOLT)

