


EZ FLOOD





Listed For Wet Locations



INSTALLATION INSTRUCTIONS

IMPORTANT

READ CAREFULLY BEFORE INSTALLING FIXTURE.
RETAIN INSTRUCTIONS FOR FUTURE REFERENCE.

RAB's EZ Flood must be wired in accordance with the National Electrical Code and applicable local codes. Proper grounding is required for safety.

The EZ Flood is for outdoor use and should not be used in areas with limited ventilation or high ambient temperatures. Installation should be done by a qualified electrician.

WARNING: Make certain power is OFF before installing or maintaining fixture.

LOCATION _

Fixture should be located at least 18" below any overhang or other structural detail. Fixture should not be recessed.

MOUNTING


The EZ Flood can be mounted to any metal 1/2" NPS mounting hole. Fixture must mounted vertically. Lamp and socket assembly may be positioned horizontally or vertically.

- 1. Route fixture leads through the mounting hole.
- 2. Twist EZ Flood foot into hole.

CAUTION: To avoid a possible shock hazard, do not connect wires until fixture is twisted into mounting hole.

WIRING

- 1. Connect the "hot" fixture lead to the supply lead.
- Connect the "common" fixture lead to "common" supply lead.
- 3. Fixture ground wire must be connected to supply ground.
- 4. Make sure connections are secure using wire nuts, crimp-on lugs or other approved connecting devices. All wiring connections in a junction box.



EZ FLOOD

INSTALLATION INSTRUCTIONS

(continued)

AIMING

- 1. Loosen swivel screw and locknut.
- 2. Aim as desired.
- 3. Retighten locking screw. Tighten locknut.

RE-LAMPING

Caution: Prior to installing, check that the lamp is of proper type and wattage. Observe lamp manufacturer's recommendations on lamp operation, ballast type and burning positions.

- 1. Disconnect power.
- 2. Make sure fixture and lamp are cool enough to touch.
- 3. Loosen the two screws on top of the die-cast hinged door frame. Open frame.
- 4. Replace lamp.
- 5. Before closing hinged door frame, make sure frame gasket is properly seated all around fixture.
- 6. Close door. Tighten screws.

CLEANING

Caution: Be sure power is off. Be sure fixture temperature is cool enough to touch.

Clean Reflector and lens with a cloth moistened with non abrasive non flamable glass cleaning solution.

TROUBLESHOOTING CHECKLIST

Check that:

- 1. Proper lamp is installed. Lamp is not faulty.
- 2. Line voltage at the fixture is proper.

- 3. Fixture is wired properly.
- 4. Fixture is grounded properly.

FACTORY INSTALLED OPTIONS

Add suffix:

/PC for photocell

Easy Installation & Product Help

Fax Back Faxed Tips & Specs, 24 hours/day. 888 RAB-1236 Tech Help Line
Call our friendly experts.
8AM - 5PM ET Mon. - Fri.
888 RAB-1000

www.rabweb.com e-mail

Visit our internet site for color product photos will be and installation tips.

Your question will be tech@ra

Your questions and requests will be answered promptly. tech@rabweb.com



THESE INSTRUCTIONS **DO NOT** COVER ALL DETAILS OR VARIATIONS IN EQUIPMENT, NOR DO THEY PROVIDE FOR EVERY POSSIBLE CONTINGENCY TO BE MET IN CONNECTION WITH INSTALLATION, OPERATION OR MAINTENANCE.