

# LED BOLLARD INSTALLATION INSTRUCTIONS

Thank you for buying RAB lighting fixtures. Our goal is to design the best quality products to get the job done right. We'd like to hear your comments. Call the Marketing Department at 888-RAB-1000, or email: marketing@rablighting.com



#### IMPORTANT

READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.
RAB fixtures must be wired in accordance with the National Electrical Code and all applicable local codes. Proper grounding is required for safety. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.

WARNING: Make certain power is OFF before installing or maintaining fixture. No user serviceable parts inside.


### LOCATION

- The Bollard should be mounted to a firm level surface.
- Anchor bolts may be used in new concrete installations. Use the provided template.
- 3. For all other applications use anchors suitable for the mounting surface.

# **ANCHOR BOLTS INSTALLATION**

CAUTION: Install according to all applicable local codes.


 Install two Anchor Bolts in concrete foundation (by others) using the template provided. Mounting Plate may be used as template. Anchor Bolts should protrude no more than 3".



#### **MOUNTING FIXTURES**

Depending on your model one or two fixtures can be mounted to each bollard.

- 1. Loosen three **Door Screws** and remove the **Door**.
- 2. Use the two #10-24 x 3/4" **Mounting Screws** to thread into the **Bollard** extrusion.
- 3. Use the nuts and lockwashers provided to secure the screws from inside the **Bollard**. Tighten securely.
- Make sure the **Housing Gaskets** are properly positioned.
- Make electrical connections from the supply wires to the fixtures using approved connectors. Strain relief the wires.
- 6. Replace the Door. Tighten screws.
- Install the Bollard Cap and Gasket and tighten the two set screws.






# **LED BOLLARD INSTALLATION INSTRUCTIONS**

#### **MOUNTING PLATE**

Assemble fixture(s) to bollard before mounting the Bollard to the Mounting Plate.

- 1. Place the Mounting Plate over Anchor Bolts.
- Use four Leveling Screws or shims to level the Mounting Plate.
- Tighten assembly using the washers, lockwashers and nuts provided.
- Make sure supply leads extend far enough to make fixture connections.
- Slide Gasket down around the bottom of the Mounting Plate.
- Use the four Mounting screws to mount the Bollard to the Mounting Plate. Tighten securely.




Note: These instructions do not cover all details or variations in equipment nor do they provide for every possible situation during installation, operation or maintenance.

#### WIRING

Universal voltage driver permits operation at 100-240V(10W) or 100-277V(13W) and at 50 or 60Hz.

- Connect the black fixture lead to the (+) LINE supply lead.
- 2. Connect the white fixture lead to the (-) COMMON supply lead.
- 3. Connect the bare copper Ground wire from fixture to supply ground.




### **CLEANING & MAINTENANCE**

CAUTION: Be sure fixture temperature is cool enough to touch. Do not clean or maintain while fixture is energized.

- Clean glass lens with non-abrasive glass cleaning solution.
- 2. Do not open fixture to clean the LED. Do not touch the LED.

## **MOUNTING PLATE DIMENSIONS**

NOT ACTUAL SIZE. Use dimensions. Use **Mounting Plate** as a template when possible.



The design of the LED Bollard is protected by U.S. patent D599,050; D599,049 and patents pending in Canada, China and Taiwan.



# Easy Installation & Product Help



# **LED BOLLARD INSTALLATION INSTRUCTIONS**

**ANCHOR BOLT TEMPLATE FOR BLED BOLLARD**Confirm dimensions before using as a template. If possible use the actual mounting plate as your template.

