

WPLED5™ INSTALLATION INSTRUCTIONS

Thank you for buying RAB lighting fixtures. Our goal is to design the best quality products to get the job done right. We'd like to hear your comments. Call the Marketing Department at 888-RAB-1000, or email: marketing @rabweb.com



IMPORTANT

READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.


RAB fixtures must be wired in accordance with the National Electrical Code and all applicable local codes. Proper grounding is required for safety. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.

WARNING: Make certain power is OFF before installing or maintaining fixture. No user serviceable parts inside.

MOUNTING

CAUTION: Suitable for wet locations in downlight position only.

- 1. Orient the **Back box** for **Conduit** entry direction, if necessary.
- 2. Place Wall Gasket and mount Back box. Use suitable hardware for mounting the surface.
- Rotate the Adaptor Plate such that Adaptor Plate Screws are at the either end of slot and the arrow showing TOP is facing up. For position of Adaptor Plate with reference to different Conduit position, see details in figure below.
- 4. Pull supply wires from back (or through **Conduit)** and wire fixture as shown in the wiring section. Fixture may hang from the tether while wiring.
- 5. Check Housing Gasket. It should remain firmly around the inside of the Housing.
- 6. Make sure all gaskets are properly seated. Align the holes on **Housing, Adaptor Plate and Back box**. Use the long **Housing Screws** provided with the kit to tighten the **Housing.**
- If outdoor surface is irregular, use weatherproof silicone sealant to seal any gaps around the Back box. Plug the unused plugs.





WPLEDR5™ INSTALLATION INSTRUCTIONS

CLEANING & MAINTENANCE

CAUTION: Be sure fixture temperature is cool enough to touch. Do not clean or maintain while fixture is energized.

- Clean glass lens with non-abrasive glass cleaning solution
- Do not remove LED lens to clean the LED. Do not touch the LED.

TROUBLESHOOTING

- Check that the line voltage at fixture is correct. Refer to wiring directions.
- 2. Is the fixture grounded properly?
- 3. Is the photocell is functioning properly (if used)?

ACCESSORIES

Frosted Lens available with the Kit.


- 1. Loosen the two screws and remove the lens frame.
- 2. Replace clear lens with frosted lens.

CAUTION: Do not touch the LED.


WIRING

Universal voltage driver permits operation at 120V to 240V, 50 or 60 Hz..

- Connect the black fixture lead to the (+) LINE supply lead.
- Connect the white fixture lead to the (-) COMMON supply lead.
- Connect the bare copper Ground wire from fixture to supply ground.



Note: These instructions do not cover all details or variations in equipment nor do they provide for every possible situation during installation, operation or maintenance.





Easy Installation & Product Help



WPLED5™ INSTALLATION INSTRUCTIONS

CLEANING & MAINTENANCE

CAUTION: Be sure fixture temperature is cool enough to touch. Do not clean or maintain while fixture is energized.

- Clean glass lens with non-abrasive glass cleaning solution.
- Do not remove LED lens to clean the LED. Do not touch the LED.

TROUBLESHOOTING

- Check that the line voltage at fixture is correct. Refer to wiring directions.
- 2. Is the fixture grounded properly?
- 3. Is the photocell is functioning properly (if used)?

ACCESSORIES

Frosted Lens available with the Kit.


- 1. Loosen the two screws and remove the lens frame.
- 2. Replace clear lens with frosted lens.

CAUTION: Do not touch the LED.


WIRING

Universal voltage driver permits operation at 120V to 240V, 50 or 60 Hz..

- Connect the black fixture lead to the (+) LINE supply lead.
- Connect the white fixture lead to the (-) COMMON supply lead.
- Connect the bare copper Ground wire from fixture to supply ground.



Note: These instructions do not cover all details or variations in equipment nor do they provide for every possible situation during installation, operation or maintenance.



Easy Installation & Product Help



WPLEDR5™ INSTALLATION INSTRUCTIONS

Thank you for buying RAB lighting fixtures. Our goal is to design the best quality products to get the job done right. We'd like to hear your comments. Call the Marketing Department at 888-RAB-1000, or email: marketing @rabweb.com



IMPORTANT

READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

RAB fixtures must be wired in accordance with the National Electrical Code and all applicable local codes. Proper grounding is required for safety. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT


AND THE HAZARDS INVOLVED.

WARNING: Make certain power is OFF before installing or maintaining fixture. No user serviceable parts inside.

MOUNTING

CAUTION: Suitable for wet locations in downlight position only.

- 1. Orient the Back box for Conduit entry direction, if necessary.
- 2. Place Wall Gasket and mount Back box. Use suitable hardware for mounting the surface.
- Rotate the Adaptor Plate such that Adaptor Plate Screws are at the either end of slot and the arrow showing TOP is facing up. For position of Adaptor Plate with reference to different Conduit position, see details in figure below.
- 4. Pull supply wires from back (or through **Conduit)** and wire fixture as shown in the wiring section. Fixture may hang from the tether while wiring.
- 5. Check Housing Gasket. It should remain firmly around the inside of the Housing.
- 6. Make sure all gaskets are properly seated. Align the holes on **Housing, Adaptor Plate and Back box**. Use the long **Housing Screws** provided with the kit to tighten the **Housing**.
- 7. If outdoor surface is irregular, use weatherproof silicone sealant to seal any gaps around the **Back box.** Plug the unused plugs.





WPLEDR5™ INSTALLATION INSTRUCTIONS

CLEANING & MAINTENANCE

CAUTION: Be sure fixture temperature is cool enough to touch. Do not clean or maintain while fixture is energized.

- Clean glass lens with non-abrasive glass cleaning solution
- Do not remove LED lens to clean the LED. Do not touch the LED.

TROUBLESHOOTING

- Check that the line voltage at fixture is correct. Refer to wiring directions.
- 2. Is the fixture grounded properly?
- 3. Is the photocell is functioning properly (if used)?

ACCESSORIES

Frosted Lens available with the Kit.


- 1. Loosen the two screws and remove the lens frame.
- 2. Replace clear lens with frosted lens.

CAUTION: Do not touch the LED.


WIRING

Universal voltage driver permits operation at 120V to 240V, 50 or 60 Hz..

- Connect the black fixture lead to the (+) LINE supply lead.
- Connect the white fixture lead to the (-) COMMON supply lead.
- Connect the bare copper Ground wire from fixture to supply ground.



Note: These instructions do not cover all details or variations in equipment nor do they provide for every possible situation during installation, operation or maintenance.





Easy Installation & Product Help