

# FLUORESCENT LIGHTS FFL-24-54-T5HO-SERIES

### **SPECIFICATIONS**

CONSTRUCTION-FFL-24-T5HO: Extruded aluminum floodlight with adjustable cast aluminum swivel

**REFLECTOR:** Highly polished specular aluminum


LENS: High-impact clear acrylic

BALLAST: 120/230/277 volt, Type 1 Outdoor, high-frequency electronic


WIRING: Standard 120 volt, black, white and ground

**MOUNTING:** None supplied, FA-26 Pedestal recommended. See Mounting section **FINISH:** Black texture polyester powder coat, optional powder coat finish available

For 2 lamp units, add -2L to catalog number










FFL-54T5HO

FFL-24T5HO

#### ORDERING INFORMATION

CATALOG NO.	DESCRIPTION	WATTAGE	LAMP SUPPLIED	STANDARD FINISH	EST. SHIP. WEIGHT	
FFL-24-T5HO-30K	24" extruded aluminum floodlight, 120v.	24w	1 x 24 watt (30°K)	Black texture	4.0 lbs.	
FFL-24-T5HO-35K	24" extruded aluminum floodlight, 120v.	24w	1 x 24 watt (35°K)	Black texture	4.0 lbs.	
FL-24-T5HO-41K	24" extruded aluminum floodlight, 120v.	24w	1 x 24 watt (41°K)	Black texture	4.0 lbs.	
FL-24-T5HO-50K	24" extruded aluminum floodlight, 120v.	24w	1 x 24 watt (50°K)	Black texture	4.0 lbs.	
FL-39-T5HO-30K	35" extruded aluminum floodlight, 120v.	39w	1 x 39 watt (30°K)	Black texture	8.0 lbs.	HIGH OUTPUT
FL-39-T5HO-35K	35" extruded aluminum floodlight, 120v.	39w	1 x 39 watt (35°K)	Black texture	8.0 lbs.	FLUORESCENTS
FL-39-T5HO-41K	35" extruded aluminum floodlight, 120v.	39w	1 x 39 watt (41°K)	Black texture	8.0 lbs.	
FL-39-T5HO-50K	35" extruded aluminum floodlight, 120v.	39w	1 x 39 watt (50°K)	Black texture	8.0 lbs.	
FL-54-T5HO-30K	47" extruded aluminum floodlight, 120v.	54w	1 x 54 watt (30°K)	Black texture	13.0 lbs.	
FL-54-T5HO-35K	47" extruded aluminum floodlight, 120v.	54w	1 x 54 watt (35°K)	Black texture	13.0 lbs.	INTERTER
FL-54-T5HO-41K	47" extruded aluminum floodlight, 120v.	54w	1 x 54 watt (41°K)	Black texture	13.0 lbs.	<b>(4</b> TL)
FL-54-T5HO-50K	47" extruded aluminum floodlight, 120v.	54w	1 x 54 watt (50°K)	Black texture	13.0 lbs.	C (ISTED



### **BEAM/GLARE CONTROL ACCESSORIES**

FA-06-5,7 1/4" Mini Hex Cell Louver for FFL-5,7
FA-09-5,7-GREEN Slue Plastic Gel for FFL-5,7
Green Plastic Gel for FFL-5,7

FA-06-9, 13 1/4" Mini Hex Cell Louver for FFL-13
FA-09-9, 13-BLUE Blue Plastic Gel for FFL-13
FA-09-9, 13-GREEN Green Plastic Gel for FFL-13

FA-06-26 1/4" Mini Hex Cell Louver for FFL-26
FA-09-26-BLUE Blue Plastic Gel for FFL-26
FA-09-26-GREEN Green Plastic Gel for FFL-26

**FA-26** Commercial Mounting Pedestal; see "Mounting Devices" section for complete details

FA-26-R Commercial Mounting Pedestal with receptacle
FA-39 Commercial Mounting Pedestal with 6 ft. power cord
-HE Hood Extension

	ŀ	8" 203mm	
4	3"   T		<b>3"</b> 76mm
J		FA-09-9, 13	


	<u> </u>
	FA-06-9, 13
	8"
	203mm
	3" 76mm
	FA-06-26
<b>→</b>	8" 203mm
j	3" 76mm

JOB INFORMATION	
Type:	Date:
Job Name:	
Cat. No.:	
Lamp(s):	
Specifier:	
Contractor:	
Notes:	
FOCUS INDUSTRIES INC. 25301 COMMERCENTRE DRIVE LAKE FOREST, CA 92630	www.focusindustries.com sales@focusindustries.com (949) 830-1350 • FAX (949) 830-3390

FSA-00													
Powder Coat Finishes	Black Texture (Standard)	Antique Verde	Bronze Texture	Camel	White Texture	Hunter Texture	Rust	Weathered Iron	Weathered Brown	Stucco	Rubbed Verde	Chrome Powder	Terra Cotta
Ordering Code	-BLT	-ATV	-BRT	-CAM	-WTX	-HTX	-RST	-WIR	-WBR	-STU	-RBV	-CPR	-TRC



### LIGHT DISTRIBUTIONS AND PHOTOMETRICS






# **FOCUS**

### **INSTALLATION INSTRUCTIONS**

Compact Fluorescent Flood Lights (120v. and 277v.)

Inspected by

- 1. Make sure electrical supply power is shut off at circuit breaker before starting fixture installation or servicing of fixture.
- Using thread sealant, thread fixture onto junction box or other mounting device (not supplied) until it is at desired direction. Tighten provided lock nut to ensure that the fixture is firmly locked to adjusted position.
- Attach fixture leads to line in leads observing polarity (black to black, white to white and green to ground) using approved silicone-filled safety wire connectors.
- Attach junction box cover plate to junction box (not supplied). Make sure that wires are not pinched between junction box cover and junction box and gasket seats flush.
- 5. Coat exposed fixture threads with thread sealant to prevent moisture from entering junction box or other mounting device.
- To adjust fixture aiming angle, loosen swivel screw. Do not remove completely. Hold fixture at selected angle and tighten swivel screw firmly with #2 Phillips screw driver.
- 7. Turn on power to the fixture and check for proper operation.



### LAMP INSTALLATION/REPLACEMENT:

### CAUTION: Do not exceed maximum wattage marked on fixture label.

- To prevent electrical shock, turn off electrical power supply before servicing.
- 2. Remove 2 side plate screws and pivot side plate.

## For question call 1-800-882-1350

- 3. Slide lens outward to expose lamp.
- 4. Replace lamp with correct wattage and type marked on fixture label.
- 5. Re-install replace front lens & side plate screws.

NOTE: Must be installed by a licensed electrician per local codes. For Questions Call 1-888-882-1350