

NOTE: THIS PRODUCT IS TO BE USED ON CEILING MOUNTED TRACK.

- **LOOP AND CHAIN MOUNT - FOR USE WITH LUMINAIRES NOT EXCEEDING 15 LBS. AND A 5 AMP LOAD.**
- **PENDANT CORD AND STRAIN RELIEF MOUNT - FOR USE WITH PENDANT CORD TYPE SVT 18AWG 3C ROUND CABLE, AND WITH LUMINAIRES NOT EXCEEDING 5 LBS. AND A 5 AMP LOAD.**

T31N HTYPE For use only with Halo LZR, L64, L65 Series, Lithonia LTS Series, Hampton Bay EC Series Track

T31N LTYPE For use only with Philips 60, 61, 91 Series Track

T31N GTYPE For use only with Nordic GES, GET Series Track

T31N For use only with Juno R, T, TU, V Series, Contech LT, LT2 Series Track

INSTALLATION INSTRUCTIONS (LOOP AND CHAIN PENDANT)

1. Remove T31N cover.
2. Install a link from the light fixture chain on the loop.
3. Insert 3 wires (or cord) from chain/fixture through bottom of loop.
4. Connect wires from fixture to T31N cover leads using wire nuts provided.
5. Connect black T31N wire to solid, black or plain wire from fixture.
6. Connect white T31N wire to identified white striped, white or ribbed wire from fixture.
7. Connect green (ground) T31N wire to bare or green wire from fixture.
8. Re-attach T31N cover with two screws securely with 8 in-lbs. of torque.

INSTALLATION INSTRUCTIONS (PENDANT CORD AND STRAIN RELIEF)

1. Remove T31N cover.
2. Remove metal loop and threaded nipple from T31N housing.
3. Install strain relief cap on pendant cord.
4. Insert pendant cord through bottom hole of T31N.
5. Install strain relief part on pendant cord.
6. Connect wires from fixture to T31N cover leads using wire nuts provided.
7. Connect black T31N wire to solid, black or plain wire from fixture.
8. Connect white T31N wire to identified white striped, white or ribbed wire from fixture.
9. Connect green (ground) T31N wire to bare or green wire from fixture.
10. Tighten strain relief cap and strain relief part together to hold pendant cord tightly in T31N housing.
11. Re-attach T31N cover with two screws securely with 8 in-lbs. of torque.

